

- At the bottom of the screen – touch MF
- On your LCD monitor - you will now see MNL in upper left of screen
- Test the manual focus – aim the lens at an object & gently turn the silver ring on the lens

5. Setting the Rule of Thirds tick-tack-toe grid

If you do not see a tic-tac-toe grid on your LCD monitor:

- Set camera to recording mode (2)
- touch two arrows in lower left of screen
- touch Q.menu icon (upper left)
- touch tic-tac-toe-grid – drop down menu appears touch tic-tack-toe grid – touch exit and return to screen

6. Audio

- Check microphone has battery loaded
- Insert microphone into shoe on top of camera
- Plug microphone cable into MIC slot in camera (under the flap on the right front side of camera)
- Plug your buds into headset slot right below the MIC port
- Turn microphone ON.

Before you shoot any footage for your project:

7. Do a test shot in the classroom with audio. (recording mode = position 2)

- Switch to viewing mode = position 1
- The first frame of your shot should appear. Tap on it – make sure it plays with audio.

8. Check how much time you have on your battery.

You are now ready to shoot your project.